

Installation instructions

Handling the funnel gun pressure adapter properly



Handling the funnel gun pressure adapter properly

Adapter thread:

Apply the enclosed threadlocker to the adapter thread. Then tighten finger-tight with a screw wrench and leave to cure.



1



4

Compressed air tank:

Connect the compressed air tank to the filling nozzle using the quick release coupling, and slowly open the compressed air source until the pressure has equalised.

Compressed air tank:

Connect the pressure tank to the adapter thread.

Important notice:

The pressure tank change must only be carried out with the equipment in a depressurised state.

For this purpose, the tank must be completely emptied.



2



5

Compressed air source:

Close the compressed air source

Important notice:

Operate the bleeder valve on the filling nozzle.

Filling nozzle:

Connect the filling nozzle finger-tight to the compressed air source.

Important notice:

Only use 200 bar of compressed air!



3



The complete set for interspersing chips.

Important notice:

During use, the valve on the funnel gun must only be opened slightly and, when not in use, it must be closed.