

Instructions for use

Gloves and cleaning cloths for priming

Handling Triflex Glass Primer correctly



Handling Triflex Glass Primer correctly

The Triflex Glass Primer set:

Single-component, quick-drying glass cleaner and glass primer, resistant nitrile gloves and lint-free cleaning cloths for processing.

The ideal complete set for pre-treatment of glass surfaces.

Processing steps

1. Clean the surface with Triflex Glass Cleaner. Volume: approx. 0.05 l/m².
2. Leave to air-dry at +20 °C for approx. 10 min.
3. Apply Triflex Glass Primer by dabbing it on. Volume: approx. 0.05 l/m².
4. Drying time approx. 15 min at +20 °C.
5. Can be recoated with Triflex PMMA waterproofing products.

GP under-gloves

Put on the white GP under-gloves from the Triflex Glass Primer set.



Nitrile gloves

Put on the nitrile gloves over the GP under-gloves. Required to protect the GP under-gloves from mechanical influences.



Ready for use

The Triflex Glass Cleaner and Triflex Glass Primer must not be used until both gloves have been put on.



4

Cleaning the glass surface

The Triflex Glass Cleaner can now be used with the blue GP cleaning cloth.



5

Priming the glass surface

Once the surface has air-dried, the Triflex Glass Primer can be processed with the green GP cleaning cloth from the set.



The complete set for pre-treatment of glass.

Triflex Primer for glass, without grinding. Please follow the instructions in the product information.



International

Triflex GmbH & Co. KG
Karlstrasse 59
32423 Minden | Germany
Fon +49 571 38780-708
international@triflex.com
www.triflex.com

